

**KITACO SHOCK ABSORBER (G260)**

CODE : 520-1122220 REMARK : FREE LENGTH : 263mm (STOCK)

APPLICATION : APE50 (AC16) / 100 (HC07) XR MOTARD50 (AD16) / 100 (HD13)

- Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

**ATTENTION (MUST READ)**

- Please ask authorized mechanic for assembling and setting. Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.
  - We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.
  - After installation, handling stability has been changed compared to stock rear shock. Please ride safely.
  - Refer to the manufacturer service manual when installation.
  - Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.
  - Do not modify the way which is not listed or it will cause damage and trouble.
- ※ Metal/resin products get discolored/rust for ages as well as how to use. Please understand when using.

**HOW TO INSTALL**

- ※ If there is a hard degradation like a blem, fatigue and wear etc on the reuse parts, please change to new ones.

- 1) Stable vehicle by using maintenance stand.
- 2) Remove seat cover, rear wheel, etc in necessary.
- 3) Remove stock rear shock and install Kitaco one.

- ※ Install upper / lower mount bolt from left side.  
 ※ Tighten upper / lower mount nut with specified torque.

**TORQUE :****UPPER MOUNT NUT : 44N · m (4.5kgf · m)****LOWER : 34N · m (3.5kgf · m)**

- 4) Adjust each parts and make sure not to loosen before riding.

**NON-STEP PRELOAD ADJUSTMENT**

Loosen lock nut to adjust adjuster position to adjust preload.

After adjusting, tighten lock nut with pin spanner.



OPTION PARTS	CODE
PIN SPANNER 150mm (Φ40~60 usable)	674-0500811
HOOK WRENCH (Φ35~75 usable)	674-0500881

株式会社 中ノ口

220330  
 3-8-13 NAGATA, HIGASHI-  
 OSAKA, OSAKA, JAPAN  
<https://www.kitaco.co.jp/>