ALUMINUM STEP BOARD				
CODE	(BLACK) 538-0	220050	(SILVER)	538-0220060
APPLICATION		CYGNUS GRYPHUS ((SEJ4J) BKG1/2	

• Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

ATTENTION! (MUST READ)

- This product is designed and made exclusive for application vehicle, do not use other models. Do not modify the way which is not listed or it will cause damage and trouble.
- We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.
- Please ask authorized mechanic for assembling and setting.
- Refer to the manufacturer service manual when installation.
- Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.
- This instruction sheet is for the instruction for genuine condition.



There might be burr on edge. Be careful of it and please wear gloves, etc to protect your hand.



Because of the material characteristic, it cannot change shape freely as rubber sheet. If the curve does not fit, please fix to install.

PACKING LIST						
FIGURE	NAME	CODE	QTY			
1	STEP BOARD / FRONT (R)	-	x1			
2	STEP BOARD / FRONT (L)	-	x1			
3	STEP BOARD / FLOOR (R)	-	x1			
4	STEP BOARD / FLOOR (L)	-	x1			
5	TAPPING SCREW M4x12	046-0595012	x24			

HOW TO INSTALL

- Place Kitaco step board temporarily matches to normal step board, make a mark to hole point.
- *Pattern side to be surface.
- Make a φ 2~3 hole to the mark point on normal step board for tapping screw.

ATTENTION!

Making hole process by drill might break parts under the step board, please be careful when processing.

- Hold Kitaco step board down to fix with tapping screw.
- * Do not install tapping screw to out side specified place.(It might break parts under the step board.)
- Tighten each bolts firmly to finish installation.

