GRAB BAR / SIDE GRIP								
CODE	GRAB BAR	(SILVER)	80-653-13000	CIDE CDID	(SILVER)	539-1300000		
		(BLACK)	80-653-13001	SIDE GRIP	(BLACK)	539-1300100		
APPLICATION	MONKEY 125 (JB02/03)							
REMARK	Cannot install grab bar and side grip together.							

Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

## **ATTENTIONS (MUST READ)**

- This instruction sheet is for the instruction for genuine condition.
- This product is designed and made exclusive for application vehicles, do not use other models. Do not modify
  the way which is not listed or it will cause damage and trouble.
- We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.
- Please ask authorized mechanic for assembling and setting.
- Refer to the manufacturer service manual when installation.
- Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.

0

Do not apply excessive force when you use rope or tie to deliver the vehicle. It might damage this product or surrounding parts.



Do not apply excessive force like turn the vehicle using this product. This is helping tool when turn vehicle.

	ΡΔΟ	KING LIST	GRAB	SIDE		
	I ACI	MING EIST	BAR	GRIP		
FIGURE	NAME		CODE	QTY		REMARK
1	GRAB BAR	SILVER (SUS)	653-1300001	v.1	-	
		BLACK (STEEL)	653-1300101	x1	-	
2	SIDE GRIP	SILVER (SUS)	539-1300001	-	v.4	
		BLACK (STEEL)	539-1300101	-	x1	
3	FLANGE CAP BOLT	M8x25	080-0560025	x2	x2	TORQUE: 26N·m (2.7kgf·m)
4	FLANGE LOCK NUT	M8-P1.25	001-0550008	x2	x2	
5	WASHER	8x18xT1.6	090-0901008	x4	x4	
6	SPACER COLLAR	8.2x18xL5	093-9000014	x2	x2	

## **HOW TO INSTALL**

- 1) Remove seat.
- 2) Install grab bar to seat rail and rear shock mounting place with attached bolt and collar. (Refer to the illustration below.) \* In case of grab bar, removing / installing left and right rear shock is required.
- 3) When installing, tighten temporarily tightened bolts firmly. Make sure not to loosen and works well each parts before riding.

## **HOW TO TAKE CARE**

SUS might rust depending on how to use.

Especially, after riding under the rain or wash, wipe water completely and apply anti-rust.



