| AERO VISOR | | | | |
|-------------|----------------------------|--|--|--|
| CODE | SMOKE: 670-1470100 | | | |
| APPLICATION | CT125 HUNTER CUB (JA55/65) | | | |

Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

ATTENTION (MUST READ)

- This product is designed and made exclusive for application vehicles, do not use other models. Do not modify
 the way which is not listed or it will cause damage and trouble.
- We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.
- Please ask authorized mechanic for assembling and setting. Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.
- Refer to the manufacturer service manual when installation.
- Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.
- This instruction sheet is for the instruction for standard condition.

HOW TO TAKE CARE THE SCREEN ATTENTION

- Under the direct sunlight, it might occur the trouble like deformation, fire, etc, because of condensing
 phenomenon due to concave mirror effect. Be careful when parking.
- When parking under direct sunlight, please block screen from direct sunlight by soft cloth, etc.
- When windy day, it is susceptible to wind, please drive at reduced speed.
- When parking with body cover on, choose a shaded and well-ventilated place.
 If you park under the high heat with body cover on, heat builds up inside, it may cause deformation.
- Be careful not to adhere battery fluid, brake fluid. It breaks screen plastic.
- Do not apply excessive force, hard bend, it may cause of broken.
- Please inspect sometimes not to loosen and backlash for additional tightening.
- Deligion of the well and a well are traversed and aging, if deterioration is remarkable, please change to new one.
- If there is a hard scratch and break, please change to new one because it might fall off.
- When screen get dirt, wipe with soft cloth or sponge with lots of water. Screen is easy to get hurt, do not use brush
- If screen gets heavy dirt, please use neutral detergent. (Using abrasive powder, etc is prohibited.) Do not use organic solvent like acid/alkaline detergent, gasoline, benzine, sinner, etc.

| PACKING LIST (Refer to the figure & illustration.) | | | | | |
|--|-------------------------|---------------|----------------|-----|--|
| FIGURE | NAME | | CODE | QTY | |
| 1 | SCREEN (T-01/universal) | SMOKE | 670-9000101 | x1 | |
| 2 | SCREEN STAY | L | 670-1470101 | x1 | |
| 3 | SCREEN STAY | R | 670-1470102 | x1 | |
| 4 | SPACER COLLAR | 6x18xL8 | 0900-093-02027 | x2 | |
| 5 | SPACER COLLAR | 6x18xL10 | 0900-093-02028 | x2 | |
| 6 | PAN HEAD(+) SCREW(B) | M5x20 | 052-0503020 | x4 | |
| 7 | WASHER (B) | 12x5.2xT1.5mm | 090-0914005 | x4 | |
| 8 | WELNUT C550 | M5x0.8 | 678-0500001 | x4 | |
| 9 | BUTTON CAP BOLT | M6x30 | 060-0550030 | x4 | |

HOW TO INSTALL

***ADVICE**

When installing, tighten each bolts temporarily, then tighten finally with adjusting left and right balance.

1) Remove head light bracket mounting bolt and head light mounting bolt.

2) Install attached (9) M6x15 bolt and genuine head light bolt by using attached spacer as illustration.

3)Install screen to holder with attached welnut, screw and washer while adjusting left and right balance.

4) Tighten finally each bolts.

ATTENTION!

- •If there is a hard degradation like a blem, fatigue and wear etc on the reuse parts, please change to new ones.
- Before installation, make sure to match the hole position of front cowl not to break it.



