

AERO VISOR		
CODE	SMOKE : 670-1850200	
APPLICATION	CB250R (FNO.MC52-1200001~)	

Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

ATTENTION (MUST READ)

- This product is designed and made exclusive for application models, do not use other models. Do not modify the way which is not listed or it will cause damage and trouble.
- We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.
- Please ask authorized mechanic for assembling and setting. Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.
- Refer to the manufacturer service manual when installation.
- Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.
- This instruction sheet is for the instruction for stock condition.

HOW TO HANDLE SCREEN

⚠ ATTENTION

- Under direct sunlight, the deformation, fire, etc trouble might occur because of condensing phenomenon due to concave mirror effect. Be careful when parking.
- In case of parking under direct sunlight, please protect screen from direct sunlight by using soft cloth, etc.
- When windy day, it is easy to get effect by wind, please ride at reduced speed.
- In case of parking with body cover on, please choose shaded and well ventilated place. If park under the high heat with body cover on, temperature increases inside and it might cause of deformation.
- Be careful not to apply battery fluid and brake fluid. It breaks screen.
- Do not apply excessive force and hard bend. It might cause of broken.
- Please check regularly to make sure not to loosen and slip. Please do additional tightening in need.
- Welnut get aging by ultraviolet rays and aging. If deterioration is remarkable, please change to new one.

HOW TO TAKE CARE

- If there is a hard scratch and break on screen, please change to new one because it might fall off.
- In case that screen gets dirt, wipe with soft cloth or sponge with lots of water. Do not use blush because screen is easy to get scratch.
- In case of screen gets heavy dirt, please use neutral detergent. Do not use abrasive powder, organic solvent, acid / alkaline detergent, gasoline, benzene, sinner, etc.

ATTENTION TO CONDENSING PHENOMENON!



PACKING LIST

FIGURE	NAME	CODE	QTY
1	SCREEN (T-01 / UNIVERSAL)	SMOKE	670-9000101 x1
2	SCREEN STAY	L	670-1850201 x1
3	SCREEN STAY	R	670-1850202 x1
4	STEPPED COLLAR	12xL28.5xL32.4	670-1850203 x2
5	STEPPED COLLAR	12xL8.5xL12.4	564-1461003 x2
6	PAN HEAD (+) SCREW (B)	M5x20	052-0503020 x4
7	WASHER (B)	12x5.2xT1.5mm	090-0914005 x8
8	WELNUT C550	M5x0.8	678-0500001 x4
9	CAP BOLT	M5x25	050-0500025 x2
10	CAP BOLT	M5x45	050-0500045 x2

HOW TO INSTALL

*ADVICE

- When installing, tighten each bolt temporarily. Then tighten firmly with adjusting balance of left and right.
- 1) Remove head light side socket bolt (2pcs) and meter back side socket bolt (2pcs).
 - 2) Install stay temporarily with attached bolt and stepped collar as illustration.
 - 3) Install screen to stay with attached welnut, screw and washer while adjusting balance of left and right.
 - 4) Tighten each bolts firmly.

ATTENTION!

- If there is a hard degradation like a blem, fatigue and wear etc on the reuse parts, please change to new ones.
- Before installation, make sure to match the front cowl hole position not to break outer cowls.

WELNUT STRUCTURE

