ORIGINAL REAR CARRIER

APPLICATION

LITTLE CUB (FNO,C50/AA01)/FI MODEL (FNO,AA01-4000001 ~) SUPER CUB50(FI MODEL)(FNO,AA01-1700001 ~) SUPER CUB 50 ** SUPER CUB CUTMIZED, ETC ARE UNINSTALLABLE.

 $(FNO,C50-0200001 \sim /AA01-1000001 \sim 1699999)$

Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

ATTENTION (MUST READ)

- This product is dress-up parts for reduce the damage when touching. (This is not designed for hard use.) Do not use for other purposes.
- This instruction sheet is for the instruction for genuine condition.
- This product is designed and made exclusive for application vehicles, do not use other models. Do not modify the way which is not listed or it will cause damage and trouble.
- Please ask authorized mechanic for assembling and setting.
- Refer to the manufacturer service manual when installation.
- Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.

PACKING LIST		
(Refer to the figure & illustration on below.)		
FIGURE	NAME	QTY
1	CARRIER	х1
2	BUTTON CAP BOLT M6x25	x2
3	COLLAR 9x10mm	x2
4	BUTTON CAP BOLT M8x25	x2
5	WASHER 9mm	x2
6	NUT 8 mm	x2



Do not apply excessive force to carrier such as using rope or tie to deliver the vehicle.

CODE : (CHROME) : 80-539-11160

It might damage the rear carrier or surrounding parts.



Do not apply excessive force like lifting the vehicle using carrier. When you use center stand, use it to helping tool.

HOW TO INSTALL

If there is a hard degradation like a blem, fatigue and wear etc on the reuse parts, please change to new ones.

Remove installation bolts of normal rear carrier and fuel tank. Then install Kitaco rear carrier with attached bolts as illustration on right side.

After installation, make sure not to loosen any parts before riding.

HOW TO TAKE CARE

Rust might occur depending on how to use. Especially, after ride under the rain, wash, etc, wipe water perfectly, then apply anti rust, etc.



