REAR CARRIER							
CODE	(BLACK) 80-539-13002	(SILVER) 80-539-13003					
APPLICATION	MONKEY 125 (JB02/03)						
REMARK	Cannot install grab bar and side grip together.						

Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

## ■ATTENTIONS (MUST READ)

- This instruction sheet is for the instruction for genuine condition.
- This product is designed and made exclusive for application vehicle, do not use other models. Do not modify the way which is not listed or it will cause damage and trouble.
- Please ask authorized mechanic for assembling and setting. Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.
- Refer to the manufacturer service manual when installation.
- Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.



Do not apply excessive force to carrier when you use rope or tie to deliver the vehicle. It might damage the rear carrier or surrounding parts.



Do not overweight on carrier.
It might damage the carrier. (Weight limit: 7.0kg)



Do not apply excessive force like lift the vehicle using this product.

This is helping tool when turn vehicle.

PACKING LIST					SILVER	
FIGURE	NAME		CODE	QTY		REMARK
1	REAR CARRIER	BLACK	539-130020BK	x1	-	
		SILVER	539-130020SL	-	x1	
2	FLANGE CAP BOLT	M8x25	080-0560025	x2	x2	TORQUE: 26N·m (2.7kgf·m)
3	FLANGE LOCK NUT	M8-P1.25	001-0550008	x2	x2	
4	WASHER	8x18xT1.6	090-0901008	x4	x4	
5	SPACER COLLAR	8.2x18xL5	093-9000014	x2	x2	

## **HOW TO INSTALL**

- 1) Remove seat.
- 2) Install rear carrier to seat rail and rear shock mounting place with attached bolt and collar. (Refer to the illustration below.)
- ※Removing / installing left and right rear shock mounting place is required.
- 3) When installing, tighten temporarily tightened bolts firmly. make sure not to loosen and works well each parts before riding.

## **HOW TO TAKE CARE**

Rust might occur depending on how to use.

Especially, after riding under the rain or washing, wipe water completely and apply anti-rust.



