

TANDEM BACK REST kit	
CODE	(LARGE PAD) 80-652-18600
APPLICATION	Rebel 250 (MC49)

Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

ATTENTION (MUST READ)

- This instruction sheet is for the instruction for genuine condition.
- This product is designed and made exclusive for application vehicles, do not use other models. Do not modify the way which is not listed or it will cause damage and trouble.
- We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.
- Please ask authorized mechanic for assembling and setting.
- Refer to the manufacturer service manual when installation.
- Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.

ATTENTION!

- This product does not have enough toughness. Do not apply excessive force to tandem back rest when you use rope or tie to deliver the vehicle. Please use back rest and support.
- Pad is not perfectly water proof. If the surface is dry, water might be penetrated by rain or wash and it might affect to passenger. Please understand before using.
- Direct sunlight or ages may cause of discolored. Please understand before using.



Do not apply excessive force to this product such as using rope or tie to deliver the vehicle. It might damage this product or surrounding parts.



Do not apply excessive force like lifting the vehicle using this product. When you turning the vehicle, use it to helping tool.

PACKING LIST		LARGE			
FIGURE	NAME	CODE	QTY	REMARK	
1	LARGE PAD	300mm	652-0500011	x1	
2	SIDE STAY	BACK REST	652-1860002	x2	
3	CENTER BRACKET	BACK REST	652-1860001	x1	
4	WASHER	8x16xT1.2	090-0900008	x4	
5	WASHER	8x22xT2.3	090-0902008	x2	For fixing pad.
6	FLANGE LOCK NUT	8mm	001-0550008	x2	
7	BUTTON CAP BOLT	M8x15	080-0550015	x4	

REMOVING GENUINE PARTS

○ Remove genuine rear frame Assy socket bolts (total 4pcs from left and right). (Refer to the illustration.)

HOW TO INSTALL

- 1) Install side stay temporarily with attached parts to rear frame Assy socket bolt (each 2) positions.
- 2) When installing stay and bracket, tighten temporarily tightened bolts firmly alternately evenly while adjusting each parts. (If you cannot install correctly, loosen all bolts and tighten additionally with adjusting.)
- 3) Make sure not to loosen any parts before riding.

GENUINE SOCKET BOLT INSTALLING / REMOVING ILLUSTRATION (LEFT AND RIGHT TOTAL 4PCS)

