

SUPER THROTTLE PIPE	CODE : 901-1432900
APPLICATION : GROM (FNO,JC61-1000001 ~ 129999/JC61-13000001 ~) / PCX (JF56) / 150 (KF18)	

• Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

ATTENTIONS (MUST READ)

- SUPER THROTTLE PIPE is designed and made exclusive for GROM, do not use on other models.
 - Do not modify the way which is not listed or it will cause damage and trouble.
 - Please ask authorized mechanic for assembling and setting.
- Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.
- Refer to the manufacturer HONDA service manual when installation
 - Bolts and nuts may get loosen by engine vibration.
- Please check and make sure each part of bolts and nuts are not loose before running.
- This instruction sheet is for the instruction with stock condition.
 - Please contact a mechanic nearby immediately when you find something unusual.

IMPORTANT POINT !
 Install cable end (STEP ①), loosen lock nut (STEP ②), turn the adjuster to adjust the freeplay, install cable end (STEP ③).
 Adjust the freeplay 2 ~ 6 mm when inspection.
 With the engine idling, turn the handlebar all the way to the right and left to ensure that the idle speed does not change.
 If idle speed increases, check the throttle grip freeplay and adjust it.

IMPORTANT POINT !
REMOVING STOCK THROTTLE PIPE
 Loosen lock nut (STEP ①), turn the adjuster to adjust freeplay, remove cable end (STEP ②) from throttle pipe, remove cable end (STEP ③) from throttle pipe.
INSTALLING KITACO THROTTLE PIPE
 Install Kitaco throttle pipe in the reverse order, adjust the throttle grip freeplay from 2mm to 6mm.
 With the engine idling, turn the handlebar all the way to the right and left to ensure that the idle speed does not change.
 If idle speed increases, check the throttle grip freeplay and adjust it.



SUPER THROTTLE PIPE	CODE : 901-1432900
APPLICATION : GROM (FNO,JC61-1000001 ~ 129999/JC61-13000001 ~) / PCX (JF56) / 150 (KF18)	

• Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

ATTENTIONS (MUST READ)

- SUPER THROTTLE PIPE is designed and made exclusive for GROM, do not use on other models.
 - Do not modify the way which is not listed or it will cause damage and trouble.
 - Please ask authorized mechanic for assembling and setting.
- Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.
- Refer to the manufacturer HONDA service manual when installation
 - Bolts and nuts may get loosen by engine vibration.
- Please check and make sure each part of bolts and nuts are not loose before running.
- This instruction sheet is for the instruction with stock condition.
 - Please contact a mechanic nearby immediately when you find something unusual.

IMPORTANT POINT !
 Install cable end (STEP ①), loosen lock nut (STEP ②), turn the adjuster to adjust the freeplay, install cable end (STEP ③).
 Adjust the freeplay 2 ~ 6 mm when inspection.
 With the engine idling, turn the handlebar all the way to the right and left to ensure that the idle speed does not change.
 If idle speed increases, check the throttle grip freeplay and adjust it.

IMPORTANT POINT !
REMOVING STOCK THROTTLE PIPE
 Loosen lock nut (STEP ①), turn the adjuster to adjust freeplay, remove cable end (STEP ②) from throttle pipe, remove cable end (STEP ③) from throttle pipe.
INSTALLING KITACO THROTTLE PIPE
 Install Kitaco throttle pipe in the reverse order, adjust the throttle grip freeplay from 2mm to 6mm.
 With the engine idling, turn the handlebar all the way to the right and left to ensure that the idle speed does not change.
 If idle speed increases, check the throttle grip freeplay and adjust it.

