




K • CON Pro

**LOOKS LIKE NO VALVE THERE!
INVISIBLE AIR VALVE
4 COLORS NEWLY RELEASED!**



Looks like there is no air valve on the wheel ! Remove aluminum cap, install straight valve and put on air !

○ MONKEY 125



⚠ STRAIGHT VALVE ⚠

It has special head shape so following parts are not usable together.

EXTENSION AIR VALVE
90° / CODE : 803-0500000
75° / CODE : 803-0500010
60° / CODE : 803-0500020

New parts (see below)
ADJUSTABLE AIR VALVE CAP
CODE : 0901-509-00100

REMOVING AIR / FILLING AIR IN WITH ITS CAP ON!



⚠ ADJUSTABLE AIR VALVE CAP ⚠

It has special head shape so following parts are not usable together.

EXTENSION AIR VALVE
90° / CODE : 803-0500000
75° / CODE : 803-0500010
60° / CODE : 803-0500020

INVISIBLE AIR VALVE SET

COLOR	CODE	PRICE
BLUE	0901-509-00010	¥ 1,800
RED	0901-509-00020	
BLACK	0901-509-00050	
SILVER	0901-509-00060	


- UNIVERSAL ● ALUMINUM MACHINED ● ALUMITE FINISH
- FOR TUBE LESS WHEEL ● APPLICABLE RIM HOLE I.D. : $\phi 11$
- WEIGHT : 9 gram ● STRAIGHT VALVE (KEY HOLDER TYPE)
- SOLD IN PAIRS

※ Smaller wheel such as 8 inch wheel not usable.
※ Almost all of tubeless wheel could be usable, but some of the wheel are not. Measure the actual wheel size before purchase.

※ Take the straight valve length into consideration, which might interfere with hub & spokes.
※ It might adjust wheel balance, as valve weight is different.

KITACO OFFICIAL YOUTUBE CHANNEL

How to install invisible air valve streaming now!!



○ FILLING AIR IN




Using straight valve head ④, remove aluminum cap ②. Remove valve holder ③, install straight valve ④ to invisible air valve ①.

ADJUSTABLE AIR VALVE CAP

CODE	PRICE
0901-509-00100	¥ 600

● UNIVERSAL ● WEIGHT : 5 gram ● SOLD IN PAIRS



KITACO OFFICIAL YOUTUBE CHANNEL

How to install adjustable air valve streaming now!!

Variety of vehicle usable !!



POINT

1. Push the top end of with finger to remove air
2. Put in air with cap on.

