

OIL CATCH TANK (CARBON)	
CODE	( BLACK ) 616-1432200 ( SILVER ) 616-1432210 ( RED ) 616-1432220
APPLICATION	GROM (JC61) Engine number : ~ JC61E-1304754
REFERENCE	The models made after JC61E-1304755 not usable as oil level gauge (oil filler cap) on R crankcase interferes.


•Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

### ATTENTIONS (MUST READ)


- The pressure inside the crankcase of high tuned engine is really high. Oil catch tank is to release the blowby gas in the air and keep the oil inside.
- We are not responsible for damages and accidents caused by assembling mistake and improper setting.
- Do not modify the way which is not listed or it will cause damage and trouble.
- Please ask authorized mechanic for assembling and setting.
- Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.
- Bolts and nuts may get loosen by engine vibration.
- Please check and make sure each part of bolts and nuts are not loose before running.
- OILCATCH TANK is designed and made exclusive for specific model, do not use on other models.
- Please do not make rapid braking / install it to extremely high output engine, which causes transmission & engine broken, which also causes severe accidents.



**FLAMMABLES**  
Inflammable high oil is used during operation.  
The use of products causing fire or smoke is strictly prohibited.



As for engine oil, during engine operation and after operation are extremely hot. Please start working after the oil cools down enough (it may be hot even when the surface is cool).



As for cylinder, crankcase, exhaust pipe, etc., during engine operation and after operation are extremely hot. Do not touch carelessly.



This instruction sheet is for the person who has basic knowledge for maintenance. Do not operate if you do not have skill and knowledge.

### SPECIFICATION

O.D.xLENGTH :  $\phi 63 \times L115\text{mm}$  CAPACITY : 220cc

### PACKING LIST (Refer to the figures & illustration right side)

FIG	NAME	CODE	QTY
1	OIL CATCH TANK (type X) BLACK	616-0501200	× 1
	OIL CATCH TANK (type X) SILVER	616-0501210	
	OIL CATCH TANK (type X) RED	616-0501220	
2	SPONGE TAPE 20 × 58 × T3mm	996-0600004	× 2
3	STAY	616-1432206	× 1
4	STAINLESS BAND 50-70mm	0900-995-01070	× 2
5	INSULATION TUBE $\phi 10 \times 360\text{mm}$	755-0900805	× 1
6	WASHER 6 × 13 × T1.0mm	090-0900006	× 1
7	HOSE 7mm × 1 m	0900-991-90003	× 1
8	CRESCENT CLAMP 12.5	995-0008006	× 5
9	NIPPLE 8X1.25 ( $\phi 8$ HOSE )	990-0800201	× 3
10	OIL FILLER CAP (BREATHER HOSE ATTACHMENT)	513-1002002	× 1
11	BUTTON CAP BOLT M8X15	080-0551015	× 1

### OPTION PARTS

LIQUID GASKETS (KC-167) 0900-969-00020

### HOW TO INSTALL

- 1) Install nipples and bolts to oil catch tank referring to below illustration.  
(Apply liquid gasket on screws)
- 2) Put the stay on stainless band temporarily, tighten with R crankcase cover bolts.  
\* Bend the clip if needed.
- 3) After placing oil catch tank, cut the hose into 3 to the length from nipple to tank.

### HOW TO CARE KEEP

- \* Below illustration is Kitaco clutch cover, but install in the same way on OEM clutch cover also.

\* The models made after JC61E-1304755 not usable as oil level gauge (oil filler cap) on R crankcase interferes.

