

IGNITION COIL (TCI/CDI) UNIVERSAL

IGNITION METHOD	TCI (Transistor Controlled Igniter)	CDI (Capacitor Discharge Igniter)
CODE	(RED) 754-9010020 (BLACK) 754-9010050	(RED) 754-9010120 (BLACK) 754-9010150
APPLICATION	Monkey125(JB02/03),Dax125(JB04),Super cub 110 (JA10),Cross cub 50(AA06),CT125 (JA55/65) etc. ※In the standard mounting position, it will interfere with the cowling, so it can be installed in the reverse (inverted) position.	For Honda single cylinder 12V CDI ignition 4st/2st vehicles.The vehicle with normal AC generator (Monkey, Cub, Ape, NSR50/80, Dio, Super Dio, Live Dio, etc.)etc.Stay, collar, etc. may be required depending on the model of the vehicle.
ATTENTION!	Only for single cylinder vehicles with TCI ignition system. Only Honda TCI vehicles have been confirmed to be compatible.	Only for single cylinder vehicles with CDI ignition system. Only Honda TCI vehicles have been confirmed to be compatible.

Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

ATTENTION (MUST READ)

- This part increases the spark of the spark plug and is expected to improve power output and pickup. It is also suitable as a repair part.
- The driver is solely responsible for any damage to this product or related parts due to improper assembly, and we assume no responsibility for any accidents that may result.
- When sparking the plug outside the cylinder for spark checks, etc., wear insulated gloves because the voltage is extremely high in this area.
- This paper is intended for those who have basic knowledge of motorcycle maintenance. Do not work on this product if you do not have the skills and knowledge.
- When installing the product, please be sure to follow the manufacturer's service manual for each vehicle model.

Features of Ignition Coil

This ignition coil increases the discharge voltage compared to the stock coil, and is expected to improve power output, response, and fuel economy.

PACKING LIST			TCI	CDI	
NAME	CODE	QTY	REMARKS		
IGNITION COIL TCI with a 500mm code	-	x1	-	BLACK/RED	
IGNITION COIL CDI with a 500mm code	-	-	x1	BLACK/RED	
WASHER 6x13x1.0mm	0900-090-02004	x4	x4	SPACER AND SHIM	

HOW TO INSTALL

IGNITION COIL

⚠

(-) is body ground CDI ignition only

HIGH TENSION CORD

PLUG CAP

IGNITION PLUG

TCI IGNITION [HONDA]
Connect the ECM (ignition signal) side cord to the green terminal of the two ignition coil terminals.

FOR BODY SIDE IGNITION COIL

IGNITION COIL SIDE BLACK ex.+(black/white)color line

GREEN ex.+(pink/blue)color line

CDI IGNITION [HONDA]
FOR BODY SIDE IGNITION COIL

IGNITION COIL SIDE BLACK ex.+(black/yellow)color line

(BODY EARTH)

- Install the ignition coil in a place where it will not interfere with driving.
- Cut the high tension cord to an appropriate length and screw it into the ignition coil and plug cap.
- ※ Be sure to allow plenty of room for the length of the product, and do not install the product taut. Also, be careful not to remove it while driving.
- After assembly, check that the engine starts up normally.
- When connecting the high-tension cord in the middle, use self-bonding tape for high pressure for complete waterproofing and wrap it around the cord before connecting.
- If the high-tension cord interferes with the stay, please install in a different direction from stock, or use a separate collar to adjust the tensioner.

⚠ The high tension cord on the ignition coil side is not detachable. Removing it may cause damage.

240219

<https://www.kitaco.co.jp/>

KITACO
株式会社キタコ