

FUEL TANK CAP COVER

CODE : 852-1435900

APPLICATION : sh mode (JF51) /Dio110 (JF58)

- Thank you for purchasing Kitaco product.
Read and understand the instruction before installing.

ATTENTION (MUST READ)


- This product is designed and made exclusive for application models, do not use other models. Do not modify the way which is not listed or it will cause damage and trouble.
 - We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.
 - Please ask authorized mechanic for assembling and setting.
 - Refer to the manufacturer service manual when installation.
 - Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.
 - This instruction sheet is for the instruction for stock condition.
- ※ Metal/resin/alumite products get discolored/rust for ages as well as how to use. Please understand when using.

PACKING LIST

NAME		QTY
FUEL TANK CAP COVER	-	1
HOLLOW SET M3x4		2
HOLLOW SET M3x5		2

ATTENTION

- ※ Tighten screw alternately evenly little by little.
- ※ Over tightening (hollow set) may cause of scratch tank cap and dent. Be careful of it.



TORQUE : 5N·m(0.5kgf·m)

Match M3x5 hollow set and dent part on genuine tank cap △ (triangle) mark.

DENT PART