KITACO SHOCK ABSORBER APPLICATION: CROSS CUB110 (JA45/60) %Not compatible with CROSS CUB50 (AA06)

CODE (SPRING COLOR)

(RED)520-1446020

(YELLOW) 520-1446030

(BLACK) 520-1446050

REMARK: ● FREE LENGTH 371mm (SAME AS GENUINE) ● PRELOAD: NON-STEP ● BLACK BODY

 Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

- ATTENTION (MUST READ)


- •Please ask authorized mechanic for assembling and setting. Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.
- •We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.
- After the installation, the steering stability has changed compared to the normal rear shock, please ride safely.
- Refer to the manufacturer service manual when installation.
- •Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.
- •Do not modify the way which is not listed or it will cause damage and trouble.
- Metal/resin products get discolored/rust for ages as well as how to use. Please understand when using.


HOW TO INSTALL

ADJUSTING NON-STEP PRELOAD Adjust preload position by loosing

lock nut. After the adjustment, tighten

 If there is a hard degradation like a blem, fatigue and wear etc on the reuse parts, please change to new ones.





3) Remove genuine rear shock, then install Kitaco one.

※Tighten upper / lower bolt (nut) with specified torque.

• UPPER / LOWER NUT : 29N·m (2.9 kgf·m)

4) Make sure not to loosen any parts before riding.



the lock nut by pin spanner.

OPTION PARTS	CODE
PIN SPANNER 150mm (Φ40~60)	674-0500801
HOOK WRENCH (Φ32~75)	674-0500850
ADJUSTABLE HOOK WRENCH (Φ35~75)	674-0500880



VEHICLE SIDE

3-8-13 NAGATA, HIGASHI-OSAKA, OSAKA, JAPAN